

Adding a Clare Video Doorbell to ClareHome Product Bulletin

Last modified: 05/08/18

Introduction

The Clare Video Doorbell Camera is added to your ClareHome automatically when using the ClareVision Plus app. Use this product bulletin to supplement the doorbell camera's instructions.

Note: You will need access to the ClareVision Plus app, the Clare Video Doorbell Quick-Start Guide, and the ClareHome app.

To add the Clare Video Doorbell to ClareHome:

 Follow the ClareVision Plus app and the Clare Video Doorbell Camera Quick-Start Guide to start adding the camera.

Note: When you add the camera, it must be connected to the same network as your CLIQ controller (2.4GHz only).

- 2. Once the camera is on the network, the camera is immediately auto-discovered in your ClareHome project and configured with the default password Secure7519. This is now the default password for the camera.
- Once the camera is auto-discovered, an error message displays in the ClareVision Plus app.



Note: This message displays because the ClareHome app has already activated the camera. This is a known issue and is being worked on.

4. Click **Cancel**, and then click the back arrow <.

DOC ID – 1600 • Rev 03

5. A second pop-up displays, click Exit.

Not activate the device? The inactivated device cannot be added to your account.

Cancel Exit

- 6. Return to the main screen and rescan the camera. There are no more errors and the camera is added to your account.
- 7. Continue following the quick-start guide's directions.
- 8. Verify that the camera added successfully, access the ClareHome app and browse to the camera's live view.
 - > CCTV > Clare Video Doorbell Camera



Contact information

Clare Controls, LLC. 7519 Pennsylvania Ave, Suite 104 Sarasota, FL 34243

General: 941.328.3991 Fax: 941.870.9646 www.clarecontrols.com

Integrator/Dealer Support: 941.404.1072

claresupport@clarecontrols.com

Homeowner Support (ClareCare): 941.315.2273 (CARE)

help@clarecontrols.com

DOC ID – 1600 • Rev 03